

Step 4

SCREW EXTRACTORS

Screw extractors allow the unscrewing of broken screws. First, the centre of the screw has to be punched properly with a centre punch. Then, a centric hole is drilled into the screw. Next, the screw extractor is twisted counter clockwise into the drilled hole. An adjustable tap wrench or a tool holder without a ratchet can be used as a holder.







according to DIN 10 breviation consists of HR (Hardness Rockwell) as an identifier for the test procedure, followed by another letter which indicates the scale and thus the test value, test procedure and the force and specimens.

standardised. Those scales are identified by the letters A-H, K, N and T. The standardised visualisation consists of the hardness scale, e.g. 65 HRC.

MAXIMAL USER TORQUE

N/IIIII terisile strengtii						
SIZE	SCREWS	DRILLS	DRILL DE	PTH TORQUE	SQUARE SHANK	TAP WRENCH
1	4 – 6	1,8	7	2,2	2	Nr, 1
2	6 – 8	3,2	10	10	3	Nr, 1
3	8 – 11	4,5	13	23	4	Nr, 2
4	11 – 14	6,5	16	70	5	Nr, 2
5	14 – 18	8,5	21	150	8	Nr, 3
6	18 – 24	11	24	180	9	Nr, 4